


RYA Levels 1 and 2

Parts of Access 303 dinghy



Access 303 dinghy

(3.03 metres long)

Mast

Mainsail

Jib

Boom




Access 303 dinghy

(3.03 metres long)

Mainsheet
Cleat

Mainsheet
(Rope)




Access 303 dinghy

(3.03 metres long)

Jib Sheet
(rope)

Jib Cleat

Jib Fairlead



Access 303 dinghy

Centreboard (3.03 metres long)
(raised)



Access 303 dinghy

(3.03 metres long)

Rudder blade



Rudder Box



Access 303 dinghy

(3.03 metres long)

(Rope)
Traveller



Access 303 dinghy

(3.03 metres long)

Joy Stick



Access 303 dinghy

Reefing Lines

